ASSEMBLY AND INSTALLATION INSTRUCTIONS

LK36453

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. The combined weight of your ceiling fan and light kit cannot exceed 35 pounds unless additional support is provided for the fan.







For Light Kit:

1. Remove the switch box cover from the switch box of the fan by loosing the three screws.
2. Unscrew the center plug from the switch box cover and discard it.
3. For fan style that is shown in Fig.1: Attach the nipple of the light kit to the hole of the switch box cover, then thread the wires through the washer and hex nut, then secure them tightly.
4. For fan style that is shown in Fig.2: Thread the fixture wire through the washer, hex nut and the switch box cover. Then attach the cap to the switch box cover, then secure it with two set screws (6x32 20mmL).
5. Pull out the wires from the switch box. Make wire connections using the wire nuts:
   ---The black wire from light kit to the black or blue wire from the fan.
   ---The white wire from light kit to the white wire from the fan.
   ---Carefully tuck wires back into the switch box.
6. Restore the switch box cover back to the switch box using the three screws.
7. Attach the glass shades to glass holders, then secure them with socket rings. (See Fig.3)
8. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
9. Turn on the power at the main fuse or circuit breaker box.
   (You can control the lights with the pull chain.)

aireRyder™
060218

For Ceiling Light: (See Fig.4 & Fig.5)



Fig.4



Fig.5

1. Take out the hex nut, washer, two bolt nuts, grounding pad and canopy from the hardware package for ceiling light.
2. Unscrew and remove the hex nut, washer and the cap from the nipple. (See Fig.4)
3. Attach the canopy with the open side facing upward to the fixture by inserting the nipple, then secure it with a washer, grounding pad and hex nut.
4. Attach two screws to the mounting strap, then secure them with two lock nuts. Adjust the length of the screws if necessary.
5. Attach the mounting strap to the outlet box by using two mounting screws.
6. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:
   ---The black wire from fixture to the black wire from the outlet box.
   ---The white wire from fixture to the white wire from the outlet box.
   ---Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.
   Carefully tuck the wires back into the outlet box.
7. Attach the canopy to the mounting strap by inserting two screws, then secure them with the bolt nuts.
8. Follow steps 7~9 as for Light Kit.